

**Projectors supported by JED T460 projector controller.  
July 5th 2008 Rev 2.76A release. Total count 1229**

3M: MP8730  
3M: MP8746  
3M: MP8747  
3M: MP8770

3M: MP8775  
3M: X45  
3M: X55  
3M: X64

3M: X70  
3M: X75  
3M: X80

Acer: 7755C

Acer: PD523 \*\* May need proj  
firmware update \* No parallel

Acer: PD723  
Acer: PD725

ASK Proxima C20  
ASK Proxima C60  
ASK Proxima C85  
ASK Proxima C90  
ASK Proxima C95  
ASK Proxima C100  
ASK Proxima C105

ASK Proxima C170  
ASK Proxima C175  
ASK Proxima C180  
ASK Proxima C185  
ASK Proxima C200  
ASK Proxima C310  
ASK Proxima C410

ASK Proxima C420  
ASK Proxima C440  
ASK Proxima C445  
ASK Proxima C450  
ASK Proxima C460

Barco: BD2100  
Barco: BD3000  
Barco: BD3100  
Barco: BD3200

Barco: BD3300  
Barco: BD5000  
Barco: BD5100  
Barco: BD6300

Barco: BD8000  
Barco: BD8100  
Barco: BG8200  
Barco: BG9200

BenQ: MP510 \*\*  
BenQ: MP610 \*\*  
BenQ: MP611 \*\*  
BenQ: MP620 \*\*  
BenQ: MP622 \*\*  
BenQ: MP720 \*\*  
BenQ: MP721/c \*\*  
BenQ: MP770 \*\*  
BenQ: PB7100  
BenQ: PB7200  
BenQ: PB7220  
BenQ: PB8140

BenQ: PB8240  
BenQ: PB8250  
BenQ: PB8253  
BenQ: PB8260  
BenQ: PB8263  
BenQ: SP820  
BenQ: SP830  
BenQ: SP831  
\*\* May need proj firmware  
update if older than June 2006  
Will need RS232 enabled and

baud rate set via factory setup  
screen. See T460 manual

\* No parallel operation allowed  
as most BenQ proj. need "Reply"  
mode

Note: quite a few BenQ  
projectors only operate at  
115200baud, so need additional  
460b speed converter.

Boxlight: MP-60e

Boxlight: MP-63e

Canon: LV-5100  
Canon: LV-5110  
Canon: LV-5210  
Canon: LV-5220  
Canon: LV-7105  
Canon: LV-7210  
Canon: LV-7215  
Canon: LV-7220  
Canon: LV-7225  
Canon: LV-7240  
Canon: LV-7245  
Canon: LV-7250

Canon: LV-7255  
Canon: LV-7300  
Canon: LV-7320  
Canon: LV-7325  
Canon: LV-7345  
Canon: LV-7350  
Canon: LV-7355  
Canon: PV-7500  
Canon: PV-7510  
Canon: LV-7525  
Canon: LV-7545  
Canon: LV-7550

Canon: LV-7555  
Canon: LV-7565  
Canon: LV-7575  
Canon: LV-X4  
Canon: LV-X5  
Canon: LV-X6  
Canon: SX6  
Canon: SX50  
Canon: SX60  
Canon: X600

Christie: DS30  
Christie: Plus 25  
Christie: DS30  
Christie: LS+58  
Christie: LU77  
Christie: LW25  
Christie: LW40  
Christie: LW300  
Christie: LW600  
Christie: LX20

Christie: LX25  
Christie: LX26  
Christie: LX32  
Christie: LX33  
Christie: LX35  
Christie: LX37  
Christie: LX40  
Christie: LX41  
Christie: LX45  
Christie: LX50

Christie: LX55  
Christie: LX65  
Christie: LX66  
Christie: LX100  
Christie: LX120  
Christie: LX380  
Christie: LX450  
Christie: MAT. 1500  
Christie: VIVID WHITE  
Christie: VIVID BLUE

DELL: 2300MP  
DELL: 2400MP

DELL: 4100MP  
DELL: 5100MP

Eiki: EIP-200  
Eiki: EIP-1000  
Eiki: EIP-1500  
Eiki: EIP-1600  
Eiki: XIP-2000  
Eiki: EIP-2500  
Eiki: EIP-3000  
Eiki: EIP-3500  
Eiki: EIP-4500  
Eiki: EIP-5000  
Eiki: EIP-S200  
Eiki: EIP-X200  
Eiki: EIP-X350  
Eiki: LC-980  
Eiki: LC-982  
Eiki: LC-HDT10  
Eiki: LC-NB1  
Eiki: LC-NB2  
Eiki: LC-NB3  
Eiki: LC-NB4  
Eiki: LC-SB10  
Eiki: LC-SB20  
Eiki: LC-SB21  
Eiki: LC-SB22  
Eiki: LC-SE10  
Eiki: LC-SD10  
Eiki: LC-SD12  
Eiki: LC-SD15  
Eiki: LC-SM1  
Eiki: LC-SM2  
Eiki: LC-SM3  
Eiki: LC-SM4  
Eiki: LC-SVGA860  
Eiki: LC-SVGA870  
Eiki: LC-SX1U

Eiki: LC-SX2U  
Eiki: LC-SX3U  
Eiki: LC-SX4XL  
Eiki: LC-SX6  
Eiki: LC-UXT1  
Eiki: LC-UXT3  
Eiki: LC-VC1  
Eiki: LC-W3  
Eiki: LC-W4  
Eiki: LC-W5  
Eiki: LC-X1U  
Eiki: LC-X2U  
Eiki: LC-X3  
Eiki: LC-X4  
Eiki: LC-X5  
Eiki: LC-X6  
Eiki: LC-X50  
Eiki: LC-X60  
Eiki: LC-X70  
Eiki: LC-X71  
Eiki: LC-X983  
Eiki: LC-X984  
Eiki: LC-X985  
Eiki: LC-X986  
Eiki: LC-X990  
Eiki: LC-X999  
Eiki: LC-X1000  
Eiki: LC-X1100  
Eiki: LC-XA20  
Eiki: LC-XB10  
Eiki: LC-XB20  
Eiki: LC-XB21  
Eiki: LC-XB22  
Eiki: LC-XB23  
Eiki: LC-XB24

Eiki: LC-XB25  
Eiki: LC-XB27  
Eiki: LC-XB28  
Eiki: LC-XB29  
Eiki: LC-XB30  
Eiki: LC-XB31  
Eiki: LC-XB33  
Eiki: LC-XB40  
Eiki: LC-XB41  
Eiki: LC-XC1  
Eiki: LC-XE10  
Eiki: LC-XG100  
Eiki: LC-XG110  
Eiki: LC-XG200  
Eiki: LC-XG210  
Eiki: LC-XG250  
Eiki: LC-XG300  
Eiki: LC-XGA970  
Eiki: LC-XGA980  
Eiki: LC-XGA982  
Eiki: LC-XM1  
Eiki: LC-XM2  
Eiki: LC-XM4  
Eiki: LC-XNB1  
Eiki: LC-XNB2  
Eiki: LC-XNB3  
Eiki: LC-XNB4  
Eiki: LC-XNB5  
Eiki: LC-XT1  
Eiki: LC-XT2  
Eiki: LC-XT3  
Eiki: LC-XT4  
Eiki: LC-XT9

Epson: EB-G5000  
Epson: EB-G5100  
Epson: EB-G5150  
Epson: EB-G5200W  
Epson: EB-G5300  
Epson: EB-G5350  
Epson: EB-G5150N (network)  
Epson: EB-G5350N (network)  
Epson: EMP-30  
Epson: EMP-50  
Epson: EMP-51  
Epson: EMP-52  
Epson: EMP-53  
Epson: EMP-54  
Epson: EMP-61  
Epson: EMP-62  
Epson: EMP-70  
Epson: EMP-71  
Epson: EMP-73  
Epson: EMP-74  
Epson: EMP-81  
Epson: EMP-82  
Epson: EMP-83

Epson: EMP-280  
Epson: EMP-400W  
Epson: EMP-500  
Epson: EMP-503  
Epson: EMP-520  
Epson: EMP-600  
Epson: EMP-700  
Epson: EMP-703  
Epson: EMP-710  
Epson: EMP-713  
Epson: EMP-720  
Epson: EMP-730  
Epson: EMP-735  
Epson: EMP-740  
Epson: EMP-745  
Epson: EMP-800  
Epson: EMP-810  
Epson: EMP-811  
Epson: EMP-820  
Epson: EMP-821  
Epson: EMP-822  
Epson: EMP-830  
Epson: EMP-835

Epson: EMP-1810  
Epson: EMP-1815  
Epson: EMP-1825  
Epson: EMP-5300  
Epson: EMP-5350  
Epson: EMP-5500  
Epson: EMP-5600  
Epson: EMP-6000  
Epson: EMP-6010  
Epson: EMP-6100  
Epson: EMP-6110  
Epson: EMP-7200  
Epson: EMP-7250  
Epson: EMP-7300  
Epson: EMP-7350  
Epson: EMP-7500  
Epson: EMP-7600  
Epson: EMP-7700  
Epson: EMP-7800  
Epson: EMP-7850  
Epson: EMP-7900  
Epson: EMP-8000  
Epson: EMP-8100

Epson: EMP-8150  
Epson: EMP-8200  
Epson: EMP-8300  
Epson: EMP-9000  
Epson: EMP-9100  
Epson: EMP-9300  
Epson: EMP-S1

Epson: EMP-TS10  
Epson: EMP-TW10  
Epson: EMP-TW20  
Epson: EMP-TW100  
Epson: EMP-TW200  
Epson: EMP-TW500  
Epson: EMP-TW520

Epson: EMP-TW550  
Epson: EMP-TW600  
Epson: EMP-TW700  
Epson: EMP-TW800  
Epson: EMP-TW1000  
Epson: EMP-TW2000

Fuji: Large number of Plasma screens, all same code.

Fuji: LPF4200  
Fuji: LPF4700

Fuji: LPF5200  
Fuji: LPF6200

Everest: EX-27020  
Everest: EX-27025

Everest: EX-28030  
Everest: EX-31025

Everest: EX-31032  
Everest: EX-31036

Hewlett Packard  
HP: vp6110 \*  
HP: vp6111 \*  
HP: vp6120 \*

HP: vp6121 \*  
HP: vp6311 \*  
HP: vp6315 \*  
HP: vp6320 \*

HP: vp6321 \*  
HP: vp6325 \*  
HP: xp8010  
HP: xp8020

Hitachi: CP-RS55  
Hitachi: CP-RS56  
Hitachi: CP-RS57  
Hitachi: CP-RS61  
Hitachi: CP-RX60  
Hitachi: CP-X20  
Hitachi: CP-X6  
Hitachi: CP-X205  
Hitachi: CP-S210  
Hitachi: CP-S S318  
Hitachi: CP-S220W  
Hitachi: CP-S225W  
Hitachi: CP-S235W  
Hitachi: CP-S240  
Hitachi: CP-X245  
Hitachi: CP-X250  
Hitachi: CP-X251  
Hitachi: CP-X253  
Hitachi: CP-X255  
Hitachi: CP-X256  
Hitachi: CP-X260  
Hitachi: CP-X265  
Hitachi: CP-X268  
Hitachi: CP-X275W  
Hitachi: CP-X300  
Hitachi: CP-X305  
Hitachi: CP-X308  
Hitachi: CP-S310W  
Hitachi: CP-S317W

Hitachi: CP-X320W  
Hitachi: CP-X325W  
Hitachi: CP-X327W  
Hitachi: CP-X328W  
Hitachi: CP-S335W  
Hitachi: CP-X340W  
Hitachi: CP-X345W  
Hitachi: CP-S370W  
Hitachi: CP-X380W  
Hitachi: CP-X385W  
Hitachi: CP-X400  
Hitachi: CP-X417  
Hitachi: CP-X420  
Hitachi: CP-X430W  
Hitachi: CP-X440W  
Hitachi: CP-X443W  
Hitachi: CP-X445W  
Hitachi: CP-X444W  
Hitachi: CP-X505  
Hitachi: CP-X600  
Hitachi: CP-X605  
Hitachi: CP-X608  
Hitachi: CP-S845W  
Hitachi: CP-S870  
Hitachi: CP-X880W  
Hitachi: CP-X885W  
Hitachi: CP-X935W  
Hitachi: CP-X940W  
Hitachi: CP-X950W

Hitachi: CP-X955W  
Hitachi: CP-X960W  
Hitachi: CP-X970W  
Hitachi: CP-X980W  
Hitachi: CP-X985W  
Hitachi: CP-X990W  
Hitachi: CP-X995W  
Hitachi: CP-X1200  
Hitachi: CP-X1230  
Hitachi: CP-X1250  
Hitachi: CP-SX1350  
Hitachi: CP-SX5500  
Hitachi: CP-SX5600  
Hitachi: ED-X10  
Hitachi: ED-X12  
Hitachi: ED-X15  
Hitachi: ED-X20  
Hitachi: ED-S3170  
Hitachi: ED-X3250  
Hitachi: ED-X3280  
Hitachi: ED-S3350  
Hitachi: ED-X3400  
Hitachi: ED-X3450  
Hitachi: PJ-TX10  
Hitachi: PJ-TX100  
Hitachi: PJ-TX200  
Hitachi: PJ-TX300

Hit Plasma: 42PD7000MA  
Hit Plasma: 42PD8800TA  
Hit Plasma: 42PMA400

Hit Plasma: 55PD8800TA  
Hit Plasma: CMP402HD  
Hit Plasma: CMP4120HD

Hit Plasma: CMP4121HD  
Hit Plasma: CMP4201  
Hit Plasma: CMP4202

InFocus: IN32  
InFocus: IN34  
InFocus: IN36  
InFocus: IN42  
InFocus: IN74  
InFocus: IN76  
InFocus: IN78

InFocus: LP225  
InFocus: LP280  
InFocus: LP290  
InFocus: LP340  
InFocus: LP350  
InFocus: LP400  
InFocus: LP425

InFocus: LP435  
InFocus: LP500  
InFocus: LP520  
InFocus: LP530  
InFocus: LP540  
InFocus: LP600  
InFocus: LP630

InFocus: LP640  
InFocus: LP650  
InFocus: LP720  
InFocus: LP725  
InFocus: LP730  
InFocus: LP735  
InFocus: LP740  
InFocus: LP750  
InFocus: LP755  
InFocus: LP790

InFocus: LP800  
InFocus: LP815  
InFocus: LP820  
InFocus: LP840  
InFocus: LP850  
InFocus: LP860  
InFocus: LP920  
InFocus: LP925  
InFocus: LP930  
InFocus: LP1000

InFocus: LP1200  
InFocus: LS110  
InFocus: SP777  
InFocus: SP5000  
InFocus: SP5700  
InFocus: SP7200  
InFocus: SP7205  
InFocus: SP7210

LG: LCD/Plasma

77 models plus 100 variations  
in 4 groups.

See manual for code allocations.

LG PROJ: RD-JT50

LG PROJ: RD-JT51

LG PROJ: RD-JT52

Mit: LCD1 LDT321V  
Mit: LCD1 LDT371V  
Mit: LCD1 LDT421V

Mit: LCD1 LDT461V  
Mit: LCD1 MDT401S  
Mit: LCD2 DV320

Mit: LCD2 DV420

Mit: EX10U  
Mit: ES100U  
Mit: EX100U  
Mit: FL7000U  
Mit: HC100  
Mit: HC900  
Mit: HC1100  
Mit: HC1500  
Mit: HC3000  
Mit: HC3100  
Mit: HC5000  
Mit: HD1000  
Mit: HD4000  
Mit: HD4900  
Mit: S/XL1U  
Mit: S/XL2U  
Mit: S/XL4U  
Mit: S/XL5U  
Mit: SL6U  
Mit: WL639U  
Mit: XL6U  
Mit: XL8U

Mit: XL9U  
Mit: S/XL25U  
Mit: XL30U  
Mit: XL550U  
Mit: XL650U  
Mit: S/X50U  
Mit: SA51U  
Mit: X70-U  
Mit: X80U  
Mit: X100E  
Mit: SD105U  
Mit: S/X120E  
Mit: S/XD200U  
Mit: X200E  
Mit: S/XD206U  
Mit: S/X250U  
Mit: S290U  
Mit: X300U  
Mit: XD300U  
Mit: XD350U  
Mit: X390U  
Mit: XD400U

Mit: S/XD420U  
Mit: S/XD430U  
Mit: S/XD420U  
Mit: XD435U  
Mit: XD450U  
Mit: XD460U  
Mit: XD470U  
Mit: XD480U  
Mit: XD490U  
Mit: XD510U  
Mit: XD1000U  
Mit: XL1550U  
Mit: XD2000U  
Mit: XL2550U  
Mit: S/X490U  
Mit: X500U  
Mit: XL5900U  
Mit: XL5950U  
Mit: XL5980U/LU  
Mit: WD2000

NEC LCD3000  
NEC LCD3210

NEC LCD4010  
NEC LCD4610

NEC NLT-40FHD100  
NEC NLT-46FHD100

NEC Plasma: PX42VM5  
NEC Plasma: PX42VP4  
NEC Plasma: PX42VP5  
NEC Plasma: PX42XM2  
NEC Plasma: PX42XM3  
NEC Plasma: PX42XM4  
NEC Plasma: PX42XM5  
NEC Plasma: PX42XR3  
NEC Plasma: PX42XR4

NEC Plasma: PX42XR5  
NEC Plasma: PX42VR5  
NEC Plasma: PX50XM3  
NEC Plasma: PX50XM4  
NEC Plasma: PX50XM5  
NEC Plasma: PX50XM6  
NEC Plasma: PX50XR4  
NEC Plasma: PX50XR5  
NEC Plasma: PX50XR6

NEC Plasma: PX60XM5  
NEC Plasma: PX60XR5  
NEC Plasma: PX61XM2  
NEC Plasma: PX61XM3  
NEC Plasma: PX61XM4  
NEC Plasma: PX61XR3  
NEC Plasma: PX61XR4

NEC: GT950  
NEC: GT1150  
NEC: GT1200  
NEC: GT2000  
NEC: GT2150  
NEC: GT5000  
NEC: GT6000

NEC: HT410  
NEC: HT510  
NEC: HT1000  
NEC: HT1100  
  
NEC: LT75Z

NEC: LT25  
NEC: LT30  
NEC: LT35  
NEC: LT80  
NEC: LT81  
NEC: LT84  
NEC: LT85

NEC: LT100  
NEC: LT140  
NEC: LT150  
NEC: LT154  
NEC: LT155  
NEC: LT156  
NEC: LT157  
NEC: LT158  
NEC: LT180  
NEC: LT220  
NEC: LT240  
NEC: LT245  
NEC: LT260  
NEC: LT265  
NEC: LT280  
NEC: LT380

NEC: MT600  
NEC: MT800  
NEC: MT810  
NEC: MT820  
NEC: MT830  
NEC: MT840  
NEC: MT850  
NEC: MT860  
NEC: MT1000  
NEC: MT1020  
NEC: MT1030

OPTOMA: DS309  
OPTOMA: DX609  
OPTOMA: EP706  
OPTOMA: EP708S  
OPTOMA: EP709  
OPTOMA: EP712E  
OPTOMA: EP719H  
OPTOMA: EP721  
OPTOMA: EP723  
OPTOMA: EP727  
OPTOMA: EP728

Panasonic: PT-AE900  
Panasonic: PT-AE1000  
Panasonic: PT-AE2000  
Panasonic: PT-AX100  
Panasonic: PT-AX200  
Panasonic: PT-D995  
Panasonic: PT-D3500  
Panasonic: PT-D4000  
Panasonic: PT-D5500  
Panasonic: PT-D5600  
Panasonic: PT-D5700  
Panasonic: PT-D7500  
Panasonic: PT-D7600  
Panasonic: PT-D7700  
Panasonic: PT-D10000  
Panasonic: PT-DW5000  
Panasonic: PT-DW5100  
Panasonic: PT-DW7000  
Panasonic: PT-DW10000  
Panasonic: PT-F100  
Panasonic: PT-FW100

NEC: MT1035  
NEC: MT1040  
NEC: MT1045  
NEC: MT1050  
NEC: MT1055  
NEC: MT1056  
NEC: MT1060  
NEC: MT1065  
NEC: MT1075

NEC: NP40  
NEC: NP50  
NEC: NP60  
NEC: NP1000  
NEC: NP1150  
NEC: NP2000  
NEC: NP2150  
NEC: NP3150  
NEC: NP3151  
NEC: NP4000  
NEC: NP4001  
NEC: VT37  
NEC: VT45  
NEC: VT46  
NEC: VT47  
NEC: VT48 \* No parallel  
NEC: VT49  
NEC: VT57

OPTOMA: EP739 \*\* May need  
proj firmware update  
OPTOMA: EP751  
OPTOMA: EP752  
OPTOMA: EP758  
OPTOMA: EP759  
OPTOMA: EP761  
OPTOMA: EP763  
OPTOMA: EP771  
OPTOMA: EP772  
OPTOMA: EP776

Panasonic: PT-F200E  
Panasonic: PT-F200NTE  
Panasonic: PT-LB50  
Panasonic: PT-LB55  
Panasonic: PT-LB60  
Panasonic: PT-LB75  
Panasonic: PT-LB80  
Panasonic: PT-L5  
Panasonic: PT-L390  
Panasonic: PT-L501  
Panasonic: PT-L502  
Panasonic: PT-L511  
Panasonic: PT-L512  
Panasonic: PT-L520  
Panasonic: PT-L555  
Panasonic: PT-L556  
Panasonic: PT-L557  
Panasonic: PT-L592  
Panasonic: PT-L595  
Panasonic: PT-L597  
Panasonic: PT-L785

NEC: VT58 \* No parallel  
NEC: VT59  
NEC: VT440  
NEC: VT460  
NEC: VT465  
NEC: VT470  
NEC: VT480 \* No parallel  
NEC: VT490  
NEC: VT540  
NEC: VT560  
NEC: VT570  
NEC: VT575  
NEC: VT580 \* No parallel  
NEC: VT590  
NEC: VT595  
NEC: VT650  
NEC: VT660  
NEC: VT670  
NEC: VT676  
NEC: VT695  
NEC: VT700  
NEC: VT770

NEC: WT600  
NEC: WT610  
NEC: WT615

OPTOMA: EP780\*\*\*  
OPTOMA: EP781  
OPTOMA: EP782/W  
OPTOMA: EP810\*\*\*  
OPTOMA: EP910\*\*\*  
\*\*\* In test  
OPTOMA: H57  
OPTOMA: EP1690 \* need f/w  
update to clear O. S. Display

Panasonic: PT-L6500  
Panasonic: PT-L6600  
Panasonic: PT-L701  
Panasonic: PT-L702  
Panasonic: PT-L711  
Panasonic: PT-L712  
Panasonic: PT-L720  
Panasonic: PT-L730  
Panasonic: PT-L735  
Panasonic: PT-L750  
Panasonic: PT-L757  
Panasonic: PT-L758  
Panasonic: PT-L759  
Panasonic: PT-L780  
Panasonic: PT-L795  
Panasonic: PT-L797  
Panasonic: PT-LB10  
Panasonic: PT-LB20  
Panasonic: PT-LB30  
Panasonic: PT-LB51  
Panasonic: PT-LC50

Panasonic: PT-LC55  
Panasonic: PT-LC56  
Panasonic: PT-LC75

Panasonic Plasma: Seven groups covered in form: TH-nnPxGrp3 to TH-nnPxGrp10  
The nn is the panel size from 37 to 103 inches.

PHANTOM: ASCII readable simulation codes transmitted for test purposes

PLANAR: PR5020

Philips: LC1341  
Philips: LC1345  
Philips: LC4027  
Philips: LC4033

PIONEER PLASMA:  
PDP-43MXE1

PLUS: U2-817  
PLUS: U2-1200  
PLUS: U4-136  
PLUS: U5-132

projectiondesign Action! (etc)  
projectiondesign evo (etc)

Proxima: DP6150  
Proxima: DP6155  
Proxima: DP6500  
Proxima: DP8200x

Samsung: LCD SyncMaster 400

Sanyo LCD: 42XR7

Sanyo: PDG-DXT10L  
Sanyo: PLC-5600  
Sanyo: PLC-8800  
Sanyo: PLC-5600  
Sanyo: PLC-8800  
Sanyo: PLC-8810  
Sanyo: PLC-9000  
Sanyo: PLC-EF10  
Sanyo: PLC-EF12  
Sanyo: PLC-EF30  
Sanyo: PLC-EF31  
Sanyo: PLC-EF60  
Sanyo: PLC-SC10  
Sanyo: PLC-SE20  
Sanyo: PLC-SL15  
Sanyo: PLC-SL20  
Sanyo: PLC-SP10  
Sanyo: PLC-SP18  
Sanyo: PLC-SP20  
Sanyo: PLC-SU07  
Sanyo: PLC-SU10  
Sanyo: PLC-SU15

Panasonic: PT-LC76  
Panasonic: PT-LC80  
Panasonic: PT-L6510

The Px is a one, two or three letter. The group is the Panasonic "generation".  
There are often one or two letters following.

Philips: LC4043  
Philips: LC4050  
Philips: LC4235  
Philips: LC4241

PDP-50MXE1  
PDP-504CMX

PLUS: U5-232  
PLUS: U5-332  
PLUS: U5-432  
PLUS: U5-532

projectiondesign eCinema (etc)  
projectiondesign F1 (etc)

Proxima: DP8400x  
Proxima: DP8500x  
Proxima: DP9240  
Proxima: DP9260

Samsung: LCD SyncMaster 460

Sanyo LCD: 47XR7

Sanyo: PLC-SU20  
Sanyo: PLC-SU22  
Sanyo: PLC-SU25  
Sanyo: PLC-SU30  
Sanyo: PLC-SU31  
Sanyo: PLC-SU32  
Sanyo: PLC-SU33  
Sanyo: PLC-SU50  
Sanyo: PLC-SU51  
Sanyo: PLC-SU55  
Sanyo: PLC-SU60  
Sanyo: PLC-SU70  
Sanyo: PLC-SW10  
Sanyo: PLC-SW15  
Sanyo: PLC-SW20  
Sanyo: PLC-SW30  
Sanyo: PLC-SW35  
Sanyo: PLC-UF10  
Sanyo: PLC-UF15  
Sanyo: PLC-WXU10N  
Sanyo: PLC-WXU30  
Sanyo: PLC-WXU30 Alt chan set

Panasonic: PT-P1SDE

Philips: LC4245  
Philips: LC4750  
Philips: PXG30I

PLUS: U5-632  
PLUS: U5-732  
PLUS: U7-132  
PLUS: U7-137

projectiondesign F2 (etc)  
projectiondesign F3 (etc)

Proxima: DP9280  
Proxima: DP9290

Sanyo: PLC-XC10  
Sanyo: PLC-XE20  
Sanyo: PLC-XE31  
Sanyo: PLC-XE32  
Sanyo: PLC-XE40  
Sanyo: PLC-XE50  
Sanyo: PLC-XF10  
Sanyo: PLC-XF12  
Sanyo: PLC-XF17  
Sanyo: PLC-XF20  
Sanyo: PLC-XF30  
Sanyo: PLC-XF31  
Sanyo: PLC-XF35  
Sanyo: PLC-XF40  
Sanyo: PLC-XF41  
Sanyo: PLC-XF45  
Sanyo: PLC-XF46  
Sanyo: PLC-XF47  
Sanyo: PLC-XF60  
Sanyo: PLC-XF70  
Sanyo: PLC-XL20  
Sanyo: PLC-XL40

Sanyo: PLC-XL50  
Sanyo: PLC-XP07  
Sanyo: PLC-XP10  
Sanyo: PLC-XP17  
Sanyo: PLC-XP18  
Sanyo: PLC-XP20  
Sanyo: PLC-XP21  
Sanyo: PLC-XP30  
Sanyo: PLC-XP40  
Sanyo: PLC-XP41  
Sanyo: PLC-XP45  
Sanyo: PLC-XP46  
Sanyo: PLC-XP50  
Sanyo: PLC-XP51  
Sanyo: PLC-XP55  
Sanyo: PLC-XP56  
Sanyo: PLC-XP57  
Sanyo: PLC-XP100  
Sanyo: PLC-XT10  
Sanyo: PLC-XR70  
Sanyo: PLC-XT11  
Sanyo: PLC-XT15  
Sanyo: PLC-XT16  
Sanyo: PLC-XT20  
Sanyo: PLC-XT21  
Sanyo: PLC-XT25  
Sanyo: PLC-XT35  
Sanyo: PLC-XU07  
Sanyo: PLC-XU10  
Sanyo: PLC-XU20  
Sanyo: PLC-XU21  
Sanyo: PLC-XU22

Sharp: LCD LC-M3700

Sharp: DT-400  
Sharp: DT-5000  
Sharp: PG-A10  
Sharp: PG-A20  
Sharp: PG-B10  
Sharp: PG-C20  
Sharp: PG-C30  
Sharp: PG-C40  
Sharp: PG-C45  
Sharp: PG-D100  
Sharp: PG-D120  
Sharp: PG-D210  
Sharp: PG-M15  
Sharp: PG-MB60  
Sharp: XG-C40  
Sharp: XG-C50  
Sharp: XG-C55  
Sharp: XG-C58  
Sharp: XG-C60  
Sharp: XG-C68

Sherwood\_LCD1

Sony LCD: FWD32/40LX2

Sony: VPL-CX61  
Sony: VPL-CX63  
Sony: VPL-CX80

Sanyo: PLC-XU25  
Sanyo: PLC-XU30  
Sanyo: PLC-XU31  
Sanyo: PLC-XU32  
Sanyo: PLC-XU33  
Sanyo: PLC-XU35  
Sanyo: PLC-XU36  
Sanyo: PLC-XU37  
Sanyo: PLC-XU38  
Sanyo: PLC-XU40  
Sanyo: PLC-XU41  
Sanyo: PLC-XU45  
Sanyo: PLC-XU46  
Sanyo: PLC-XU47  
Sanyo: PLC-XU48  
Sanyo: PLC-XU50  
Sanyo: PLC-XU51  
Sanyo: PLC-XU55  
Sanyo: PLC-XU56  
Sanyo: PLC-XU58  
Sanyo: PLC-XU60  
Sanyo: PLC-XU70  
Sanyo: PLC-XU73  
Sanyo: PLC-XU74  
Sanyo: PLC-XU75  
Sanyo: PLC-XU78  
Sanyo: PLC-XU83  
Sanyo: PLC-XU84  
Sanyo: PLC-XU86  
Sanyo: PLC-XU87  
Sanyo: PLC-XU88  
Sanyo: PLC-XU88 Alt chan. set

Sharp: LCD LC-M3710

Sharp: XG-C330  
Sharp: XG-C335  
Sharp: XG-C430  
Sharp: XG-C435  
Sharp: XG-C465  
Sharp: XG-E1100  
Sharp: XG-E1200  
Sharp: XG-E3000  
Sharp: XG-E3500  
Sharp: XG-F210X  
Sharp: XG-F260X  
Sharp: XG-MB50  
Sharp: XG-MB55  
Sharp: XG-MB65  
Sharp: XG-MB70  
Sharp: XG-NV1  
Sharp: XG-NV2  
Sharp: XG-NV3  
Sharp: XG-NV4  
Sharp: XG-NV5

Sony LCD: KLHW26/32

Sony: VPL-CX85  
Sony: VPL-CX86  
Sony: VPL-CX100

Sanyo: PLC-XU100  
Sanyo: PLC-XU101  
Sanyo: PLC-XU105  
Sanyo: PLC-XU110  
Sanyo: PLC-XU110 Alt chan. set  
Sanyo: PLC-XU111  
Sanyo: PLC-XU111 Alt chan. set  
Sanyo: PLC-XU115  
Sanyo: PLC-XU111 Alt chan. set  
Sanyo: PLC-XW10  
Sanyo: PLC-XW15  
Sanyo: PLC-XW20  
Sanyo: PLC-XW50  
Sanyo: PLC-XW55  
Sanyo: PLC-XW56  
Sanyo: PLC-XW60  
Sanyo: PLV-1  
Sanyo: PLV-20  
Sanyo: PLV-30  
Sanyo: PLV-60  
Sanyo: PLV-70  
Sanyo: PLV-75  
Sanyo: PLV-80  
Sanyo: PLV-HD10  
Sanyo: PLV-WF10  
Sanyo: PLV-WF20  
Sanyo: PLV-Z1  
Sanyo: PLV-Z2  
Sanyo: PLV-Z3  
Sanyo: PLV-Z4  
Sanyo: PLV-Z5

Sharp: XG-NV6  
Sharp: XG-NV7  
Sharp: XG-P10  
Sharp: XG-P20  
Sharp: XG-P25  
Sharp: XG-PH50X  
Sharp: XG-V10  
Sharp: XR-10  
Sharp: XR-20  
Sharp: XV-Z10  
Sharp: XV-Z90  
Sharp: XV-Z91  
Sharp: XV-Z100  
Sharp: ZV-Z2000  
Sharp: ZV-Z3000  
Sharp: ZV-Z3100  
Sharp: ZV-Z10000  
Sharp: ZV-Z12000  
Sharp: ZV-Z20000  
Sharp: ZV-Z21000

Sony: VPL-CX120  
Sony: VPL-CX125  
Sony: VPL-CX150

Sony: VPL-CX155  
Sony: VPL-ES3  
Sony: VPL-ES4  
Sony: VPL-EX3  
Sony: VPL-EX4  
Sony: VPL-FE40  
Sony: VPL-FX40

Sony: VPL-PX11  
Sony: VPL-PX20  
Sony: VPL-PX21  
Sony: VPL-PX30  
Sony: VPL-PX31  
Sony: VPL-PX32  
Sony: VPL-PX35

Sony: VPL-PX40  
Sony: VPL-PX41  
Sony: VPL-FX50  
Sony: VPL-FX51  
Sony: VPL-FX52  
Sony: VPL-VW10  
Sony: VPL-VW12

TEAC PLASMA  
PLMSDM1060

PLMHDM1065  
PLMHDM1275

Toshiba: TDP-D1  
Toshiba: TDP-D2  
Toshiba: TDP-EX20  
Toshiba: TDP-EW25  
Toshiba: TDP-MT200  
Toshiba: TDP-MT400  
Toshiba: TDP-S3  
Toshiba: TDP-S8  
Toshiba: TDP-S10  
Toshiba: TDP-S20  
Toshiba: TDP-ST20  
Toshiba: TDP-SW20  
Toshiba: TDP-S25  
Toshiba: TDP-SC25  
Toshiba: TDP-SW25  
Toshiba: TDP-S35  
Toshiba: TDP-SC35  
Toshiba: TDP-SW35  
Toshiba: TDP-S21  
Toshiba: TDP-SC21  
Toshiba: TDP-T3  
Toshiba: TDP-T8  
Toshiba: TDP-T9  
Toshiba: TDP-T30  
Toshiba: TDP-T40  
Toshiba: TDP-T45  
Toshiba: TDP-T60  
Toshiba: TDP-T61  
Toshiba: TDP-T70  
Toshiba: TDP-T71  
Toshiba: TDP-T80  
Toshiba: TDP-T90  
Toshiba: TDP-TW90  
Toshiba: TDP-T91  
Toshiba: TDP-T95  
Toshiba: TDP-TW95  
Toshiba: TDP-T98  
Toshiba: TDP-T99  
Toshiba: TDP-TW99  
Toshiba: TDP-T100

Toshiba: TDP-TW100  
Toshiba: TDP-T250  
Toshiba: TDP-TW250  
Toshiba: TDP-TW300  
Toshiba: TDP-T350  
Toshiba: TDP-TW350  
Toshiba: TDP-T355  
Toshiba: TDP-TW355

---

Toshiba: TLP-250  
Toshiba: TLP-251  
Toshiba: TLP-260  
Toshiba: TLP-261  
Toshiba: TLP-380  
Toshiba: TLP-381  
Toshiba: TLP-450  
Toshiba: TLP-451  
Toshiba: TLP-470  
Toshiba: TLP-471  
Toshiba: TLP-550  
Toshiba: TLP-551  
Toshiba: TLP-560  
Toshiba: TLP-561  
Toshiba: TLP-650  
Toshiba: TLP-651  
Toshiba: TLP-670  
Toshiba: TLP-671  
Toshiba: TLP-680  
Toshiba: TLP-681  
Toshiba: TLP-710  
Toshiba: TLP-711  
Toshiba: TLP-780  
Toshiba: TLP-781  
Toshiba: TLP-790  
Toshiba: TLP-791  
Toshiba: TLP-B2  
Toshiba: TLP-MT7E  
Toshiba: TLP-S30  
Toshiba: TLP-S40

Toshiba: TLP-S41  
Toshiba: TLP-S70  
Toshiba: TLP-S71  
Toshiba: TLP-S80  
Toshiba: TLP-SW80  
Toshiba: TLP-S81  
Toshiba: TLP-S200  
Toshiba: TLP-S201  
Toshiba: TLP-S220  
Toshiba: TLP-S221  
Toshiba: TLP-T50  
Toshiba: TLP-T400  
Toshiba: TLP-T401  
Toshiba: TLP-T500  
Toshiba: TLP-T501  
Toshiba: TLP-T520  
Toshiba: TLP-T521  
Toshiba: TLP-T600  
Toshiba: TLP-T601  
Toshiba: TLP-T620  
Toshiba: TLP-T621  
Toshiba: TLP-T700  
Toshiba: TLP-T701  
Toshiba: TLP-T720  
Toshiba: TLP-T721  
Toshiba: TLP-WX2200  
Toshiba: TLP-X10U  
Toshiba: TLP-X11U  
Toshiba: TLP-X20U  
Toshiba: TLP-X21U  
Toshiba: TLP-X2000  
Toshiba: TLP-XC2000  
Toshiba: TLP-XD2000  
Toshiba: TLP-X2500  
Toshiba: TLP-XC2500  
Toshiba: TLP-X3000  
Toshiba: TLP-XC3000  
Toshiba: TLP-X4500

VIEWSONIC: PJ358  
VIEWSONIC: PJ510  
VIEWSONIC: PJ552  
VIEWSONIC: PJ562  
VIEWSONIC: PJ656  
VIEWSONIC: PJ658

VIEWSONIC: PJ750  
VIEWSONIC: PJ758  
VIEWSONIC: PJ759  
VIEWSONIC: PJ760  
VIEWSONIC: PJ853  
VIEWSONIC: PJ862

VIEWSONIC: PJ1158  
VIEWSONIC: PJ1065  
VIEWSONIC: PJ1165  
VIEWSONIC: PJ1172



(Remote terminal for 2 connected T460s)

\* **No parallel** means that “Reply” mode must be used with these projectors, and so only **one** projector can be connected to one or two T460s.

\*\* **May need proj firmware update** means that a communications chip may have to be changed at a service centre, or new firmware may have to be downloaded to the projector before RS232 communications can be used.